

Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Киргизия (996)312-96-26-47

Россия (495)268-04-70

Казахстан (772)734-952-31

<https://leitenberger.nt-rt.ru/> || bge@nt-rt.ru

ILLUMINATION TESTERS - TRACTOR TESTERS

ADAPTER FROM 7 POLE PLUG TO 13 POLE SOCKET



item number :
VK 27 (080329)

DESCRIPTION

- Adapter from 7 pole, 12 V plug (DIN/ISO 1724) to 13 pole, 12 V socket (ISO 11446).

ADAPTER FROM 13 POLE PLUG TO 7 POLE SOCKET



item number :
VK 26 (080327)

DESCRIPTION

- Adapter from 13 pole, 12 V plug (ISO 11446) to 7 pole, 12 V socket (DIN/ISO 1724).

TRACTOR TESTER FOR TESTING THE TRACTOR'S PLUG SOCKET



item number :
ZWT 01 (080203)

DESCRIPTION

- Train wagon tester for checking the socket on the train wagon
- Display by LEDs with integrated load resistors
- 7-pin, 12 V (DIN/ISO 1724)
- Integrated load resistors for rear fog light cut-off* and indicators
- CAN bus capable
- Test functions:
 - turn signal
 - Brake lights
 - Tail lights
 - Rear fog light

*If a trailer with rear fog light is used, it must be ensured that it is switched off on the towing vehicle. The rear fog light on the towing vehicle must be switched on and off automatically by inserting or removing the plug. (Operating rules are specified in the German Road Traffic Approval Regulations (StVZO) § 49a; 6/96).

TRACTOR TESTER FOR TESTING THE TRACTOR'S PLUG SOCKET



item number :
ZWT 02 (080204)

DESCRIPTION

- Train wagon tester for checking the socket on the train wagon
- Display by LEDs with integrated load resistors
- Plug 7-pin, 24 V (DIN/ISO 1185)
- Integrated load resistors for rear fog light cut-off* and indicators
- CAN bus capable
- Test functions:
 - turn signal
 - Brake lights
 - Tail lights
 - Rear fog light

*If a trailer with rear fog light is used, it must be ensured that it is switched off on the towing vehicle. The rear fog light on the towing vehicle must be switched on and off automatically by

inserting or removing the plug. (Operating rules are specified in the German Road Traffic Approval Regulations (StVZO) § 49a; 6/96).

TRACTOR TESTER FOR TESTING THE TRACTOR'S PLUG SOCKET



item number :
ZWT 20 (080247_1)

DESCRIPTION

- Tractor tester for testing the tractor's plug socket. The tester is fitted with load resistors.
- LEDs for individual functions and 5 m (16.4 ft) cable provide for use in the workshop and maintenance garage.
- Vehicles with CAN-bus can also be tested.
- plug 13-pole, 12 V (ISO 11446)
- integrated load resistors for flashers and rear foglamp

- Test functions:
flashers, brake lights, tail lights, reversing light, rear foglamp.

- Note: Tractor unit tester with alternative test plug connectors, e.g. 15-pole, 24 V, available on request.

TRACTOR VEHICLE TESTER 12 V, CAN BUS-CAPABLE, FOR CONTROLLING OF 13-POLE SOCKET OF TOWING VEHICLE



item number :
ZWT 40 (080249_2)

DESCRIPTION

- Tractor vehicle tester 12 V, CAN bus-capable, for controlling of 13-pole socket of towing vehicle.
- The individual switches and testing lights such as tail lights, brake lights, indicators, reverse lights and rear fog lights are integrated in the test case and can be individually switched on or off.

- Testing can be carried out by one person from the driver's seat with a connection cable of length 5,00 m (16.4 ft).
- 13-pole plug 12 V (ISO 11446)
- function test and failure test for individual incandescent lamps
- power supply by continuous positive and/or charging line

EQUIPMENT

- VK 26 (080327) adapter from 13-pole plug 12 V (ISO 11446) to 7-pole socket.

Архангельск (8182)63-90-72
 Астана (7172)727-132
 Астрахань (8512)99-46-04
 Барнаул (3852)73-04-60
 Белгород (4722)40-23-64
 Брянск (4832)59-03-52
 Владивосток (423)249-28-31
 Волгоград (844)278-03-48
 Вологда (8172)26-41-59
 Воронеж (473)204-51-73
 Екатеринбург (343)384-55-89
 Иваново (4932)77-34-06

Ижевск (3412)26-03-58
 Иркутск (395)279-98-46
 Казань (843)206-01-48
 Калининград (4012)72-03-81
 Калуга (4842)92-23-67
 Кемерово (3842)65-04-62
 Киров (8332)68-02-04
 Краснодар (861)203-40-90
 Красноярск (391)204-63-61
 Курск (4712)77-13-04
 Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
 Москва (495)268-04-70
 Мурманск (8152)59-64-93
 Набережные Челны (8552)20-53-41
 Нижний Новгород (831)429-08-12
 Новокузнецк (3843)20-46-81
 Новосибирск (383)227-86-73
 Омск (3812)21-46-40
 Орел (4862)44-53-42
 Оренбург (3532)37-68-04
 Пенза (8412)22-31-16

Пермь (342)205-81-47
 Ростов-на-Дону (863)308-18-15
 Рязань (4912)46-61-64
 Самара (846)206-03-16
 Санкт-Петербург (812)309-46-40
 Саратов (845)249-38-78
 Севастополь (8692)22-31-93
 Симферополь (3652)67-13-56
 Смоленск (4812)29-41-54
 Сочи (862)225-72-31
 Ставрополь (8652)20-65-13

Сургут (3462)77-98-35
 Тверь (4822)63-31-35
 Томск (3822)98-41-53
 Тула (4872)74-02-29
 Тюмень (3452)66-21-18
 Ульяновск (8422)24-23-59
 Уфа (347)229-48-12
 Хабаровск (4212)92-98-04
 Челябинск (351)202-03-61
 Череповец (8202)49-02-64
 Ярославль (4852)69-52-93

Киргизия (996)312-96-26-47

Россия (495)268-04-70

Казахстан (772)734-952-31

<https://leitenberger.nt-rt.ru/> || bge@nt-rt.ru